

# Mobile Chicken Coop Extension Module Assembly Instructions

Included in this add-on module:

- 1 x Sheeted Steel Roof Panel
- 2 x Mesh Panels
- 1 x Floor Brace
- 10 x M6 x 50mm
- 4 x M6 x 35mm
- 28 x M6 washers
- 14 x M6 LOCK nuts

**If you are retrofitting this extension module to an existing unit:**

**Please note: This add-on module must be inserted in a middle section of your existing unit between the front and rear sections – it cannot attach to either end.**

Simply remove the bolts of a middle section join and insert the mesh walls, roof and floor brace in the same manner as originally assembled. Once the new section is fixed in the middle, ensure all bolts are snugly tightened (but not over tightened).



**For initial assembly with 2 Panel base model to make a 3 or 4 panel unit:**

Follow the detailed instructions included in your base model and use these parts as required to assemble the base model into a 3 or 4 panel unit.

**NOTE: DO NOT clean your unit with bore water, bleach or any other chemicals that will affect the rust prevention treatments on the components of this unit or your warranty will be void**